



Installation instructions
FZH + SPRING & FZHM

THE MOUNTS ARE SENT AS FOLLOWS:

- A sticker on the top.



- A plastic cap on the bottom.



THE STICKER AND THE CAP ARE USED FOR THE FOLLOWING:

- Protect the thread when the concrete is poured with the sticker.
- Avoid any concrete filtering through the bottom of the mount thanks to the cap.
- The sticker is cut out to lift the slab or remove the cover to insert or change the internal spring.



- This sticker and plastic cap **must not be removed at any time.**